


SHAD

HONDA VFR CROSSTOURER 1200 '12 CRF 1000L AFRICA TWIN '16

KIT TOP H0CR12ST



1 261445 x1 →
261446 x1 ←



2 261451 x4
Ø14 Ø9 x 15



3 304032 x4
M8x50 din 9021



4 303020 x4
Ø8



5 303017 x4
M8



6 303025 x4
Ø10

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

